

# Wristband Instruction Manual

(For WB-L series / M series / S series)

Thank you very much for purchasing this Epson product.

To use the wristband safely and correctly, read the usage and safety instructions in this sheet, and also read the User's Manual for the printer.

## ! [Usage Precautions]

- Do not use the wristband when a user has a skin problem or wound on a part where the wristband is to be put.
- Do not use the wristband for the person whose skin is extremely weaker.
- In order to secure breathability, please put on the wristband with the margin of two or more fingers.
- Depending on user's constitution (such as allergic or hypersensitive tendency) and body part, a skin abnormality such as eczema or irritation may be found.  
In such case, immediately stop using the wristband, and consult a physician.
- Especially for putting the wristband on a newborn, use it with careful attention to the skin condition.  
Check the skin condition once or twice a day while using the wristband.
- When using the wristband continuously for a long period, check the dirt, damage or printed condition on the wristband and replace it with a new one appropriately.
- Do not open the snap forcibly once you fix it. Doing so may injure your finger or nail. Also, do not reuse the snap once you fix it.
- Keep the wristband away from small children.
- Be careful not to put the wristband in your mouth or let it touch your eyes and mucous membranes directly.
- The wristband will cut out for safety, if it pulls by strong power. Be careful not to hang of clothes, a hard thing, etc.
- This wristband is dedicated for the TM-C3400 printer (firmware: Ver.WSN00170 or later, printer driver: Ver.1.2.0.0 or later).


## [Recommended Print Setting]

Print setting: "Wristband Type2" (Use as "black mark receipt (roll paper).")


Print area: Lay out print data so that it fits in the shaded area of the illustration below.

<CAUTION: Do not print outside of the print area. Doing so may damage the printer or contaminate the inside of the printer.>


### WB-L series



### WB-M series



### WB-S series



[Unit: mm]  
[The values are design center values.]